9. PCB Diagrams

9-1 VCR Main ---------- 9-2

9-2 DVD Main ---------- 9-4

9-3 Function-Timer (DVD-V85K/V72K/V55K/V52K)---------- 9-5

9-4 Function-Timer (DVD-V12500/V12000/SV-DVD2EK) ---------- 9-6

9-5 Function-Timer (DVD-V52) ---------- 9-7

9-1 VCR Main

COMPONENT SIDE



CONDUCTOR SIDE



9-2 DVD Main

COMPONENT SIDE



SOLDER SIDE



9-3 Function-Timer (DVD-V85K/V72K/V55K/V52K)

COMPONENT SIDE



CONDUCTOR SIDE



9-4 Function-Timer (DVD-V12500/V12000/SV-DVD2EK)

COMPONENT SIDE



CONDUCTOR SIDE



9-5 Function-Timer (DVD-V52)

COMPONENT SIDE



CONDUCTOR SIDE



MEMO